

15" x 5"
15" x 6"
15" x 7"

REAR BRAKES
FORD 1984 & NEWER

NOTE...


HOW TO

DETERMINE BORE SIZE:

APPLICATION	SHOE SIZE	BORE SIZE
B-600 Only 15,000 Lb Axle	15" x 5"	1-5/8"
B-600 or B-700 17,500 Lb Axle	15" x 6"	1-3/4"
B-700 Only 17,500 Lb & Larger	15" x 7"	1-3/4"

- Wheel Cylinder
LK7378 L.H. - 1-5/8" Bore (New)
LK7380 R.H. - 1-5/8" Bore (New)
LK7379 L.H. - 1-3/4" Bore (New)
LK9044 L.H. - 1-3/4" Bore (Reman)
LK7381 R.H. - 1-3/4" Bore (New)
LK9045 R.H. - 1-3/4" Bore (Reman)

BRAKE LINES & HOSES

- 
LK7624 Hoses
LK0657 Steel Lines

Tappet Head & Manual Override Ass'y.
Fits 1-5/8" or 1-3/4" Bore
LK7386

LK2308

Adjustment Tool


Wheel Cylinder Adjuster Service Kit
LK7391 for 1-5/8" Bore
LK7392 for 1-3/4" Bore

Wheel Cylinder Seal Kit (contains 2 ea. seal)
LK7779 for 1-5/8" Bore
LK7795 for 1-3/4" Bore

Park Brake Switch
LK2527


Expander Piston Kit
LK7387 L.H. - 1-5/8" Bore
LK7389 R.H. - 1-5/8" Bore
LK7388 L.H. - 1-3/4" Bore
LK7390 R.H. - 1-3/4" Bore

PARK BRAKE VALVE


LK2821 New
LK2826 Reman

LK6576
Residual Check Valve

NOTE:
Lower Adjuster uses the same service parts as the Upper Adjuster.



BRAKE SHOES

BRAKE SHOE SIZE	REBUILT (1) LINED BRAKE SHOE	NEW (1) LINED BRAKE SHOE	NOTES
15" x 5"	LK7396	LK7399	For B-600 Only w/15,000 LB Axle
15" x 6"	LK7397	LK7400	For B-600 & B-700 w/17,500 LB Axle
15" x 7"	LK7398	LK7401	For B-700 Only w/17,500 LB & Larger Axles

LK7395 (L.H. - Streetside)
LK7394 (R.H. - Curbside)
 Cross-over Pipe Kit

LK7361 L.H. (Streetside)
LK7393 R.H. (Curbside)

Plug Set
LK7781

Cap Screw Set
LK7782

LK2315
Spring Removal Tool

LK7783
Port Insert

Expander Unit

- LK7382** L.H. - 1-5/8" Bore (New)
LK7384 R.H. - 1-5/8" Bore (New)
LK7383 L.H. - 1-3/4" Bore (New)
LK9046 L.H. - 1-3/4" Bore (Reman)
LK7385 R.H. - 1-3/4" Bore (New)
LK9047 R.H. - 1-3/4" Bore (Reman)

LK9000
BRAKE DRUMS

Spring Brake O-Ring
JK9744

Wedge Service Kit
Fits 1-5/8" or 1-3/4" Bore
LK7799

Reman
LK6570
Spring Brake

LK7784



TECHNICAL BULLETINS

- LK0651** How to Reduce Brake Fluid Leaks
LK7890 Brake System Troubleshoot Guide
LK0025 How To Install Brake Shoes
LK4449 Lucas Brake Repair Manual
LK7896 How to Cage the Spring Brakes
LK2194 Spring Brake Chamber Sealing
LK7485 How To Install Spring Brakes

Expander Seal Kit
LK7376 for 1-5/8" Bore
LK7377 for 1-3/4" Bore